

INDUSTRY

DIMITROL R32

REDUCING OF FREE FORMALDEHYDE

Appearance: colourless liquid

pH in solution at 10%: 5 - 6

25 - 30%Active substance:

PROPERTIES

DIMITROL R32 has been developed to respect the regulations regarding the content of free formaldehyde in the skins.

DIMITROL R32 complexes the free formaldehyde in the skin, transforming it into a soluble product, move it away from the skin to the bath, eliminating it with a simple wash.

DIMITROL R32 does not affect the final article, nor the color of the skin. With the use of **DIMITROL R32** you can get the results that current regulations require.

DIMITROL R32 can be used in all types of leather.

USAGE METHOD

Using **DIMITROL R32** from 1 to 2% in the final washing stage, with rotation of thirty minutes, you will have a reduction of free formaldehyde lower than 10ppm.